


STAINLESS STEEL VACUUM COOL BOTTLE Model SD-H

Instruction Manual



- Please read these instructions before use, and keep for future reference.
- The illustrations used in this instruction manual may differ from the actual product you have purchased.

Important Safeguards Be sure to follow the instructions.

These WARNINGS and CAUTIONS are intended to prevent property damage or personal injury to you and others.

The degree of danger or damage by the misuse of the product is indicated as follows:

WARNING Indicates risk of serious injury or death.

Indicates risk of injury or CAUTION property damage if mishandled

Prohibited or required actions are indicated as follows:

Indicates a prohibited operation.



Indicates a requirement or instruction that must be followed.

♠ WARNING

Never allow infants or small children to play with the product.

Never fill with hot beverages.

Do not play or engage in activities with the Carrying Strap Set wrapped around your neck.

↑ CAUTION

Do not use if water enters the interior of the Vacuum Laver. If the internal water seeps out from the Vacuum Laver, drinking it may cause illness.

Vacuum Layer

Do not let the Carrying Strap Set come in direct contact with your bare skin. It may cause injuries.

Do not swing the bottle by the Carrying Strap Set.

Do not drink out of the product while driving.


Do not use this product for other than storing and keeping beverages cold.


Do not hold the product by the Lid Set, Lid Cover, or Button Cover when carrying it. The product may fall and cause injuries.

Do not disassemble the Main Body.


Do not heat in a microwave, as doing so may cause sparks.

> Do not place near open flames (from gas stoves, etc.), on top of electric heaters, or IH cooking devices, as doing so may cause a fire or malfunction.










of the Main Body.

Sticker

Do not place cans, bottles, etc.



Place the product vertically when carrying in a bag to prevent leakage or condensation.

Note: The rattling noise that may be heard when the Main Body is shaken comes from the metallic foil used in the vacuum insulation to increase cold retention, and does not indicate a malfunction.

How to Use:

- Follow the instructions for care and wash the product thoroughly before use.
- When you first use the product, there may be a plastic smell. However, this
 will become less noticeable with use.

1 Open the Button Cover.



2 Open the Lid Cover.



3 Close the Lid Cover and then the Button Cover.

Close the Lid Cover and Button Cover securely until they click.




About the Carrying Strap Set


How to Detach the Carrying Strap Set

Detach the Latches from the Main Body.

Detach the three Latches from the Latch Receptacles on the Main Body by pressing the tops of the Latches in the direction of the arrow while keeping them upright.




How to Disassemble the Carrying Strap Set




How to Assemble the Carrying Strap Set


- 1 Pass the Carrying Strap through the Nameplate.
- 2 Pass the Carrying Strap through the Adjuster and then push it out in the direction of the arrow.



How to Attach the Carrying Strap Set



How to Attach the Handle Strap



How to Take Care of Your Product:

- Clean the product after each use to prevent odors and mold, and to keep the product sanitary.
- Always disassemble the product before cleaning.

When Cleaning Your Product:

- · Do not boil or use a dishwasher or dish-dryer.
- Do not clean using paint thinner, polishing powders, abrasive cleansers, scrub brushes (nylon, metal wire, etc.), melamine sponges, the nylon side of an abrasive sponge, or any similar items.
- Do not use bleach as it may damage the product.
 Zojirushi's designated cleaning detergent SB-ZA01E may be used to clean the interior of the Main Body and the Lid Set.
- The Main Body is fully washable, but do not soak it in water for an extended period of time.
 If the product is not going to be used for an extended period, wash
- If the product is not going to be used for an extended period, wash thoroughly and dry well. Store the product away from high temperatures and humidity.

Regular Care

Main Body Lid Set	Using warm water and mild dishwashing liquid, wash the Lid Set and the outside of the Main Body with a sponge, and the inside of the Main Body with a soft sponge with a handle. Use a small brush if necessary. Rinse, wipe away remaining water, and leave to dry thoroughly. Streaks or smudges caused by rubbing on the coated portion of the Main Body can be removed using a soft eraser.
Carrying Strap Set	Wipe with a soft cloth soaked in warm water and wrung thoroughly.

Dealing with Stubborn Dirt

Rust Spots and Water Stains	Fill the Main Body with hot water with 10% vinegar without attaching the Lid Set. After 30 minutes to an hour, wash the interior thoroughly.
Tea and Coffee Stains	Remove the Lid Set and use Zojirushi's cleaning detergent SB-ZA01E. (Contact Zojirushi Customer Service or your local dealer for further information.)

Replacing the Lid Set:

We take care in only using materials that are safe and hygienic for food contact. However, if plastic parts become damaged or their surface becomes rough, please replace them for optimum performance. The Lid Set may need to be replaced due to time and wear. Please check them about once a year. When replacing parts, please record the model number and part name beforehand. Then contact either the store where you purchased the product or Zojirushi Customer Service. Replacement parts may be available for an additional charge.