


Stainless Steel Tumbler

Model **SX-H**

Instruction Manual

Name of Each Part



- Please read these instructions before use, and keep for future reference.
- The illustrations used in this instruction manual may differ from the actual product you have purchased.

Important Safeguards

Be sure to follow the instructions.

These **WARNINGS** and **CAUTIONS** are intended to prevent property damage or personal injury to you and others.

■ The degree of danger or damage by the misuse of the product is indicated as follows:



WARNING

Indicates risk of serious injury or death.



CAUTION

Indicates risk of injury or property damage if mishandled.

■ Prohibited or required actions are indicated as follows:



Indicates a prohibited operation.



Indicates a requirement or instruction that must be followed.

SX-H-4E (E/K/T/C) / C

WARNING



Do not allow infants or small children to use this product. Keep out of the reach of infants and small children.

Never fill with hot beverages when using the Lid Set.

CAUTION



Do not attach parts other than those specifically designed for this product.

Do not disassemble the product (other than parts designed to be disassembled).

Do not shake the product.

Do not use the product if its thermal insulation performance has deteriorated.

Do not use if water enters the Vacuum Layer.

Drinking the water that seeps out from the Vacuum Layer may cause illness.

Vacuum Layer



Do not drink beverages directly through the Hole on the Lid.

Do not fill with or discard beverages through the Hole on the Lid or through the Straw.

Do not hold the product by the Lid Set when carrying, as the product may fall and cause injuries.

Do not place near heat sources such as gas stoves, ovens, and heaters, as doing so may cause burns or product malfunction.

Do not place near open flames (from gas stoves, etc.), on top of electric heaters, or IH cooking devices, as doing so may cause a fire or malfunction.

Do not heat in a microwave, as doing so may cause sparks.

Avoid dropping or hitting against hard surfaces.

Do not drink out of the product while driving.

Do not place dry ice in the product.

Do not pierce the product with ice picks or other sharp objects.

Do not place cans or bottles inside the Main Body. Doing so may cause a malfunction.

Do not scratch or rub the design on the outside of the Main Body strongly using fingernails or hard objects, as this may cause the design to come off.

Do not remove the sticker on the bottom of the Main Body.

Sticker





Do not fill the Main Body above the Maximum Fill Line (Raised Line.)

Drink Level



Make sure that the Lid Gasket is securely attached during use.

When using a vehicle drink holder:

- Make sure that the product sits securely inside the drink holder.
- Do not subject the product to strong shaking or vibration.

Thoroughly clean the inside and Mouth of the Main Body, and the Lid Set after every use. Be particularly careful after filling the product with sports drinks.

Consume beverages within the same day.

Leftover contents may spoil.

Break large ice cubes into smaller pieces before using, as failure to do so may cause deformation of the Main Body.

This product is not leak proof. Be very careful that it does not tip over.


Note: The rattling noise that may be heard when the Main Body is shaken comes from the metallic foil used in the vacuum insulation to increase cold retention, and does not indicate a malfunction.

How to Use:


- Follow the instructions for care and wash the product thoroughly before use.
- When you first use the product, there may be a plastic smell. However, this will become less noticeable with use.
- The stainless steel body of the Tumbler may give off a metallic odor, however this is a normal property of stainless steel.

Remove the Lid Set and fill the Main Body with a beverage.

① Pull out the Straw.



② Remove the Lid from the Main Body and fill the Main Body with a beverage.




• Never fill with hot beverages when using the Lid Set.

To attach the Lid Set, perform the above procedure in reverse.

Disassembling the Lid Set:

Remove the Lid Gasket.


Remove the Lid Gasket starting from the Notch.



Assembling the Lid Set:

Attach the Lid Gasket.

Attach the Lid Gasket, making sure that the Tab is facing out.



How to Take Care of Your Product:

- Clean the product after each use to prevent odors and mold, and to keep the product sanitary.
- Always disassemble the product before cleaning.

When Cleaning Your Product:

Please follow these instructions to prevent damage to the product:

- Do not boil.
- Do not use a dishwasher or dish-dryer on the Lid Set.
- Do not clean using paint thinner, polishing powders, abrasive cleansers, scrub brushes (nylon, metal wire, etc.), melamine sponges, the nylon side of an abrasive sponge, or any similar items.
- Do not use bleach as it may damage the product.
Zojirushi's designated cleaning detergent SB-ZA01E may be used to clean the interior of the Main Body and the Lid.
- The Main Body is fully washable, but do not soak it in water for an extended period of time.
- If the product is not going to be used for an extended period, wash thoroughly and dry well. Store the product away from high temperatures and humidity.

How to Take Care of Your Product: continued

How to Clean

- ① Wash using warm water and mild dishwashing liquid with a sponge.
Use a small brush or a soft sponge brush with a handle to wash parts that are difficult to wash.
- ② Rinse, leave to dry so there is no remaining water.
Thoroughly flush the inside of the Straw with strong running water.
- Streaks or smudges caused by rubbing on the coated portion of the Main Body can be removed using a soft eraser.
- Parts of the exterior of the Main Body may become lightened from cleansers or water stains. If this occurs, pour hot water over the discolored portion, and then immediately wipe it with a dry, soft cloth.
Be careful not to scald yourself.

How to Clean Rust Spots and Water Stains

- ① Fill the Main Body with hot water with 10% vinegar.
- ② Leave for 30 minutes to an hour without attaching the Lid Set.
- ③ Wash the interior thoroughly.

Tea, Coffee, and Other Stubborn Stains (Main Body interior and Lid Set)

Remove the Lid and use Zojirushi's cleaning detergent SB-ZA01E. (Contact Zojirushi Customer Service or your local dealer for further information.)

Replacing the Lid Set:

We take care in only using materials that are safe and hygienic for food contact. However, if plastic parts become damaged or their surface becomes rough, please replace them for optimum performance. The Lid Set may need to be replaced due to time and wear. Please check it about once a year. When replacing parts, please record the model number and part name beforehand. Then contact either the store where you purchased the product or Zojirushi Customer Service. Replacement parts may be available for an additional charge.